


## At a Glance

### Hub



1. Strobe (Red)
2. Siren
3. Power port (+12VDC)
4. Tamper switch
5. Battery on/off switch
6. Configuration button
7. Front cover
8. Backplate
9. Indicator (Blue)

### Strobe (Red)

| What you see | What it means        |
|--------------|----------------------|
| Blinking     | Alarming ( 150 FPM ) |
| Solid        | Pairing/Sniffer mode |

## How to connect to alarm hub


**STEP 1.** click **configuration button three times** on your siren, then the siren goes into the pairing/sniffer mode with light on and ready to connect to alarm hub.

**STEP 2.** Trigger your alarm hub an alarm to send a transmission signal to the siren, then the siren gives a long beep of successful indication.

## How to disconnect with alarm hub

Click **configuration buttons more than 10 times** until the siren lights on , then the siren restarts. The factory reset is now completed.

## Wireless strobe siren User Guide



1

## Welcome

This strobe siren is a wireless siren with the sound volume up to 110dB, and it is furnished bright LEDs. It is connected to the alarm hub via eV1527 protocol, with an effective communication range of up to 100 meters without obstacles. If the electrical power is lost, the backup battery built-in the siren provides power operation up to 3 hours.

## In The Box

Strobe Siren x1  
Power Adapter x1  
Mounting Screws x2  
User Guide x1

## Specifications

Power Supply: +12VDC, 1000mA  
Backup Battery: 3.7V, 500mAh Lithium Battery  
Consumption: <150mA@normal  
Alarm Volume: 110dB@powered by 12VDC  
Radio Frequency: 433Mhz  
Operation Temperature: -10~55°C

2